



TiForged Air Double Foot Casting Guide Kit Spacing

Spacing measured in inches from tip top ring to guide ring, starting from the tip.

Rod Length	Rear Grip Length*	1	2	3	4	5	6	7	8	9	10
6'6"	8"	4"	8 1/4"	12 3/4"	17 3/4"	23 1/2"	31"	40 1/4"			
7'0"	10"	4"	8 1/4"	12 5/8"	17 1/4"	22"	27 3/4"	35"	44 1/4"		
7'4"	10"	4"	8"	12 1/4"	16 1/2"	21"	26"	31 3/4"	39"	48 1/2"	
7'6"	11"	4"	8"	12 1/4"	16 1/2"	21"	26"	31 3/4"	39"	48 1/2"	
7'9"	11"	4 3/8"	8 3/4"	13 3/8"	18 1/2"	24 1/2"	32"	40"	50 1/2"		
7'11"	12"	4 3/8"	8 5/8"	13 1/2"	18 5/8"	24 3/4"	33"	41"	51 1/4"		
8'0"	12"	4 3/8"	8 5/8"	13 1/2"	18 5/8"	24 3/4"	33"	41"	51 1/4"		
8'6"	14"	4 1/4"	8 1/2"	13 1/4"	18 3/8"	23 3/4"	29 5/8"	37"	45 3/4"	56 1/4"	
9'0"	14"	4 1/4"	8 1/2"	13 1/4"	18 3/8"	23 3/4"	29 1/2"	35 1/2"	43"	51 3/4"	62 1/4"

*Rear Grip Length is measured from the butt to the rear edge of the reel seat.

The guide spacing shown in this chart is a general recommendation suitable for many applications. However, you may need to adjust it slightly to better fit your specific rod blank and application needs.