



TiForged Air Micro Casting Guide Kit Spacing

Spacing measured in inches from tip top ring to guide ring, starting from the tip.

Rod Length	Rear Grip Length*	1	2	3	4	5	6	7	8	9	10	11	12	13
6'0"	7"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19 1/2"	25"	32"	40 1/2"				
6'3"	7"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19 3/8"	24"	29 1/4"	36 18"	43 1/2"			
6'6"	8"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19 3/8"	25 5/8"	30 5/8"	27 3/8"	45 3/8"			
6'9"	9"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19 1/4"	23 3/4""	28 5/8"	34"	39 3/4"	47 1/2"		
6'10"	9"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19 1/4"	23 3/4""	29"	34 1/2"	40 5/8"	48 1/2"		
7'0"	10"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19"	23 1/2"	28 1/2"	34 3/8"	41 1/4"	49 1/2"		
7'2"	10"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19 1/4"	23 3/4""	29 1/2"	35 3/8"	42 3/4"	51 1/2"		
7'3"	10"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	15"	19 3/8"	24 1/8"	29 5/8"	36"	43 3/4"	52 1/2"		
7'4"	11"	2 1/2"	5 1/4"	8 1/4"	11 3/4"	15 1/4"	19 3/8"	24 1/8"	29 5/8"	36	43 5/8"	51 5/8"		
7'6"	11"	2 1/2"	5 1/4"	8 1/4"	11 5/8"	15"	19 1/4"	23 3/4""	28 3/4"	34"	39 1/4"	45 3/4"	54"	
7'9"	12"	2 1/2"	5 1/4"	8 1/4"	11 5/8"	15"	19	23 1/4""	27 1/2"	32 1/4"	37"	42 1/2"	48 3/4"	54"
7'11"	12"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	14 7/8"	18 7/8"	23 3/16"	27 3/4"	32 1/2"	37 1/2"	43 1/4"	50 3/8"	58 3/8"
8'0"	12"	2 1/2"	5 1/4"	8 1/4"	11 1/2"	14 7/8"	18 7/8"	23 1/4""	27 5/8"	33"	38 3/8"	44 1/4"	51 1/4"	59 1/2"

*Rear Grip Length is measured from the butt to the rear edge of the reel seat.

The guide spacing shown in this chart is a general recommendation suitable for many applications. However, you may need to adjust it slightly to better fit your specific rod blank and application needs.